

## MONTGOMERY COUNTY FIRE AND RESCUE SERVICE DRIVER/OPERATOR TRAINING PROGRAM

## Practical Application Guide Sheet

Engine: Class B Foam Handline

**Candidate Performance Competency:** Candidate will place in service a 200' 1 3/4" hoseline using booster tank water to flow Class B foam. The evaluator will let the candidate know what type of fuel (hydrocarbon or polar solvent) is to be extinguished. Candidate will select the proper percentage of Class B concentrate to be introduced into the line.

Task	Value	Score
1. Stop Engine and apply parking brake.	3	
<ol> <li>Engage pump. Listen for pump and air compressor to engage.</li> <li>See speedometer reading approximately 10-15 MPH. See green "Ok To Pump When Lit" indicator light in cab illuminated.</li> </ol>		
3. Place wheel chock on downhill side of front or rear tire. (CFP)	3	
<ul> <li>4. Operator confirms the following:</li> <li>a) Pump panel gauges are illuminated,</li> <li>b) FoamLogix Pump is on,</li> <li>c) Air Compressor is on,</li> <li>d) positive discharge pressure on the Master Discharge Gauge, and</li> <li>e) "Tank To Pump" valve is open.</li> </ul>	3	
5. Turn off FoamLogix Pump and Air Compressor. (CFP)	5	
<ul> <li>6. Set up the hose line to flow foam:</li> <li>a. Connect foam eductor to water and concentrate discharges on the pump panel.</li> <li>b. Attach 200' of 1 ¾" hose with Metro 1 fog nozzle to discharge side of the eductor. (CFP)</li> <li>c. Secure air aspirating attachment to Metro 1 nozzle. (CFP)</li> </ul>	5	
7. Set foam concentrate percentage on the eductor based on the type of fuel (hydrocarbon 1% / polar solvent 3%.) <b>(CFP)</b>	5	
8. Open Class B foam gate valve on the pump panel.	4	
9. Open TPM control device to sufficient pressure. (CFP)	3	
10. Operate primer until water discharges to ground.		
11. Open gate valve on pump panel to allow foam solution to fill the line. Assistant will completely open the nozzle bale.		

Rev. 1/13/16 Page 1 of 3

Task	Value	Score
12. Throttle up to proper discharge pressure. (200 psi at the eductor inlet) <b>(CFP)</b> Discharge Pressure:psi	5	
13. Adjust TPM to appropriate pressure. <b>(CFP)</b>		
14. Check attack line to ensure charging, freedom from obstructions, and remove all kinks missed by crew. (CFP)	5	
15. Ensure that there is a means for water to be constantly circulating through the pump for cooling in the event that lines are shut down. TRV should <u>not</u> activate. <b>(CFP)</b>	5	
16. Monitor pump panel, pump, engine compartment gauges and radio.	3	
Return to Service	•	•
17. Throttle down to 100psi. Close Class B foam gate valve and transition pickup tube to a bucket of clean water. Flush the hose and appliances while moving the eductor concentrate selector knob through each setting. (CFP)	5	
18. Throttle down, close discharge, and disengage pump.	5	
19. Reset TPM to zero. (CFP)	5	
20. Refill tank water and Class B solution reservoir.	5	
21. Ensure Engine is ready for service.	5	
22. Flush onboard Class B system with garden hose inlet on the pump panel.	5	
Additional Knowledge:		
23. Candidate will explain the 3 methods of applying Class B foam concentrate to prevent agitation of the fuel. (roll-on, bank-down, rain-down)	4	
24. Given a full reservoir of Class B foam concentrate (25 gallons) and an unlimited external water source. Candidate will explain how much foam solution is available at the 1% and 3% settings. (1% = 2,500 gallons / 3% = 833 gallons)	5	
Total Points	100	

## **Critical Fail Points**

Failure to successfully perform any of the following components will result in an automatic failure of this evolution regardless of total score.

- a) Not delivering the requested product
- b) Improper setting of the TPM at any stage of the evolution
- c) Loss of water/pressure in attack line

Rev. 1/13/16 Page 2 of 3

- d) Not flowing line at 200 PSI at eductor
- e) Improper eductor setting for solution percentage
- f) Placing greater than 200' of hose between the eductor and nozzle
- g) Failure to connect air aspirating attachment to nozzle
- h) Failure to properly flush line and Eductor
- i) Failure to turn OFF CAFS Air Compressor
- j) Failure to turn OFF Class A Foam Pump
- k) Failure to use wheel chock
- I) Activation of TRV

Evaluator: Initial beside the final outcome of the exam below.		
PASS FAIL – Overall Points	FAIL – Critical Failure Point	
Evaluator Name	 Date	
Evaluator Signature		

Rev. 1/13/16 Page 3 of 3